

DEPARTMENT OF ECOLOGY  
Water Resources Program / Dam Safety Office

**Recommended protocols for using NRCS storms  
for the dam safety inflow design flood**

**Western Washington – NRCS/SCS type 1A storm**

**Climatic Regions 5, 151, 142, 15, 154, 31, 32**

Compiled by Martin Walther, P.E., Dam Safety H/H specialist  
October 14, 2009

Objective:

Identify a combination of NRCS 24-hour storms with intensity and volume characteristics equivalent to the Dam Safety design storms as described in Technical Note 3, for use in H/H software that does not easily allow user-specified storm hyetographs.

Procedures:

1. Downstream hazard; Design step.

Conduct a dam failure analysis to identify the inundation area and the population and/or other resources at risk from a dam failure. Compute the design step per Tech Note 2 and spreadsheet DesStep.

2. Design precipitation

Compute the long-duration storm rainfall per Tech Note 3 (Oct 2009) and spreadsheet PrecipLookup3-Long. For the appropriate design step, identify the 24-hour scaling precipitation  $P_{sd}$ , and the 72-hour total storm precipitation for the long duration storm (call this  $P_T$ ). Compute the incremental precipitation  $P_T - P_{sd}$ .

Compute the short- and intermediate-duration storm rainfalls per Tech Note 3 (Oct 2009) and spreadsheets PrecipLookup1-Shrt and PrecipLookup2-Intm. For the appropriate design step, identify the total storm precipitation for each storm. Compare these total storm values to the 24-hour scaling precipitation  $P_{sd}$  computed above. Use the largest of these three rainfall values as the revised 24-hour scaling precipitation  $P_{sd}$ .

If the total storm rainfall from the short- or intermediate-duration storm is substituted for the original 24-hour  $P_{sd}$ , the incremental precipitation  $P_T - P_{sd}$  will need to be recalculated. If the revised  $P_{sd}$  exceeds the original 72-hour  $P_T$ , an antecedent storm is not needed, just a 24-hour design storm per item 5 below.

### 3. Peak storm intensity

To obtain a peak 60-minute rainfall with an NRCS type 1A storm that matches the peak 60-minute rainfall of the Dam Safety short-duration storm, a 24-hour NRCS rainfall that equals or exceeds 4.47 times the short-duration total storm rainfall is required.

Multiply the previously calculated total storm precipitation for the short-duration storm times 4.47. Compare this value to the 24-hour scaling precipitation  $P_{sd}$  computed above in step 2. Use the larger of these two rainfall values as the 24-hour scaling precipitation  $P_{sd}$ . Use this adjusted value for 24-hour  $P_{sd}$  for further storm computations per items 4 and 5 below.

If the 24-hour  $P_{sd}$  is increased to match the peak intensity of the short-duration storm, the incremental precipitation  $P_T - P_d$  will need to be recalculated. If the adjusted  $P_{sd}$  exceeds the original 72-hour  $P_T$ , an antecedent storm is not needed, just a 24-hour design storm per item 5 below.

### 4. Antecedent storm

Compute the runoff from a 24-hour NRCS storm with rainfall equal to the incremental precipitation  $P_T - P_{sd}$  (as calculated per item 2 or adjusted per item 3). If using the NRCS curve number method, use CN's for AMC-II. Note the peak water level that occurs in the pond/reservoir from this storm.

### 5. Design storm

Compute the runoff from a 24-hour NRCS storm with rainfall equal to the 24-hour scaling precipitation  $P_{sd}$  (as revised per item 2 or adjusted per item 3). If using the NRCS curve number method, use CN's for AMC-III. (If an antecedent storm is not needed, use CN's for AMC-II.) Use the peak water level in the pond or reservoir from the antecedent storm as the initial water level in the pond/reservoir for the design storm. Compare the peak water level from the design storm with freeboard requirements per Guidelines Part IV, Section 4.6, and spreadsheet FreeBoard.

[end]